

# T-PROP

## TEMPORARY SUPPORT PROP.

**1**

Mandatory PPE to be worn according to mines' standards. Make safe and mark prop position and clean floor to solid ground.

**2**

Select the correct prop size and quantity to suit the panel. Place prop at 90 degrees to strata into demarcated position.

**3**

3A. Ensure that the 'F-mark' faces the front.  
3B. Make sure that the cam is at lowest position. Extend the outer cylinder. Insert attached pin into the appropriate hole.

**4**

Fit lifting tool to cam-nut.

**5**

Push lifting tool to tighten cam...

**6**

...repeat until solid contact to roof is achieved.

**7**

Disengage lifting tool and secure using the fastening loop.

**8**

Release the lifting tool and affix the tool into the release position of the cam. 8A. Attach the 5m safety sling onto the handle hook and the pigtail to the pin. From a safe supported distance yank the safety sling thereby releasing the prop. With the safety sling still attached, drag the prop to a selected and safe area. Store the prop in a safe selected area for the next installation.

CODE	DESCRIPTION	INSTALLATION LENGTH		WEIGHT KG
		MIN	MAX	
400413	T2	0.90	1.35	21
400415	T3	1.00	1.50	23
400421	T4	1.30	2.10	27
400426	T5	1.60	2.65	31
400433	T6	2.10	3.30	36
400441	T7	2.90	4.10	43
400448	T8	3.60	4.80	47

**SABS**  
ISO 9001  
[www.elbroc.co.za](http://www.elbroc.co.za)

**ELBROC**  
MINING PRODUCTS (PTY) LTD  
Factory: 19 Brewery Street, Isando, South Africa P.O. Box 261, Isando, 1600  
Tel: +27 11 974 - 8013 Fax: +27 11 974 - 2019 E-mail: [sales@elbroc.co.za](mailto:sales@elbroc.co.za)